

## 手动风机启动器（FMS）

一系列风机启动器适用于N系列风机，较小的NCF系列风机和NOM过滤器









包括电机过载保护  
Both for single and three-phase

|    |              |
|----|--------------|
| 品名 | 手动风机启动器（FMS） |
|----|--------------|



## 手动风机启动器 ( FMS )

| [image]   | 产品名称          | 安培数 ( 安 ) | 产品编号     |
|---|---------------|-----------|----------|
|    | FMS 18 – 25   | 18 – 25   | 14503137 |
|    | FMS 14.5–19   | 14,5 – 19 | 14503037 |
|    | FMS 1–1.6 F   | 1,0 – 1,6 | 14502137 |
|    | FMS 1.6 – 2.5 | 1,6 – 2,5 | 14502237 |
|    | FMS 2.5 – 4.0 | 2,5 – 4,0 | 14502337 |
|   | FMS 4.0 – 6.3 | 4,0 – 6,3 | 14502437 |
|  | FMS 6.3 – 10  | 6,3 – 10  | 14502537 |
|  | FMS 10 – 16   | 10 – 16   | 14502637 |